

PROTOMATIC

1005

1005-00-453-5826	TRACK, ROTOR, FRONT, RH
1005-00-501-3540	STOP, REAR, CARTRIDGE
1005-00-600-8934	Blade, Front Sight
1005-00-608-5096	PLUNGER, RETAINER
1005-00-610-8910	Block, Pintle Clamping
1005-00-614-7893	SLIDE, RETRACTING
1005-01-041-9264	PIN, CAM
1005-01-048-8572	Riser, Rear Sight
1005-01-051-0354	INSULATOR, VERTICAL
1005-01-085-5163	STRIKER
1005-01-095-0330	Handle, Handwheel
1005-01-110-7633	CLEAT
1005-01-114-0068	Retainer, Bearing
1005-01-188-7879	RETAINER, SCREW INSTALLATION DLVICL
1005-01-204-4354	LOOP, LANYARD
1005-01-470-9082	LUG, POSITIONING
1005-01-497-9099	Stop, Depression
1005-01-497-9100	Stop, Elevation

1010

1010-00-438-7375	STOP BARREL
1010-01-032-9027	LUG
1010-01-043-7482	Cap
1010 01-123-6655	LOCK, LEVER DRIVE
1010 01-123-6698	PLUNGER, LOCK
1010-01-123-6699	LOCK, LEVER DRIVE
1010-01-151-6215-2	PLUNGER, FEED THROAT

1015

1015-00-615-9236	ROD, SPRING
1015-00-921-5212	Slide
1015-00-956-4540	Piece mat Dev: HR M1044 ASTM A575
1015-01-073-9703	Retainer
1015-01-079-1828	HOOK
1015-01-176-8762	BLOCK
1015-01-224-7789	LEVER Deviation 4140
1015-01-258-7833	BLOCK Upgraded material 4140

1025

1025-00-111-2731	LEVER Rod Rammer
------------------	------------------

1055

1055-01-142-2582	SLIDE, FRONT L.H.
1055-01-162-9597	PIN, GUIDE
1055-01-162-9603	Rod, Support, Reel

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

1095

1095-00-325-5015	Link, Bomb Rack Tie Linkage Latch
1095-00-593-0258	Ring, Breech Cap
1095-00-934-1449	Sleeve Launching Tube Adapter
1095-00-955-3182	Rod End, Switch Actuator
1095-01-461-0347	LINER, BREECH CHAMBER

1233

12335002	CLAMP, HALF
12335004	CLAMP, HALF

1240

1240-00-346-8155	Cell, Objective
1240-00-864-6541	RING, RETAINING
1240-00-864-6543	RING, RETAINING
1240-01-079-3047	Retainer
1240-01-122-9897	Blade

1440

1440-00-659-8571	HANDLE, RELEASE, RETENTION MECHANISM
------------------	--------------------------------------

1450

1450-00-407-3023	MOUNT, TRUNNION, OUTSIDE, ROLL CYLINDER
------------------	---

1560

1560-00-628-5771	Spool Paratroop Static Line Retriever
1560-00-657-9511	FAIRLEAD ASSY GEAR BOX AIR BAFFLE
1560-01-118-3285	ARM BOMB BAY DOOR VALVE SAFETY LOCK, -101

1620

1620-00-707-5572	RING MLG FWD TORQUE STRUT
1620-00-711-5101	Crank Control Nose Wheel Steering
1620-00-884-0348	Shear Plug Axle Inner Cylinder Assy Tip Protection Gear B-52 Acft
1620-01-311-2897-3	KEY LOCK

1630

1630-00-509-4238	SLEEVE-STATOR DRIVE, BRAKE ASSY; B-52 ACFT Deviation: Cyanide to Carbonitritide.
------------------	---

PROTOMATIC

1670

1670-00-786-9524 BOLT ASSEMBLY, PRECOM PRESSION R.H. LATCH

1710

1710-00-872-5471-1 UPPER TAPE GUIDE (Shown)
1710-00-872-5471-2 UPPER TAPE GUIDE (Opposite)
1710-00-872-5472-1 UPPER TAPE GUIDE (Shown)
1710-00-872-5472-2 UPPER TAPE GUIDE (Opposite)

1730

1730-00-025-2951 Cross Member, Aircraft Maintenance Platform
1730-00-212-4413 Manifold Oxygen Servicing Trailer Control Panel
Material Deviation: Comp 22 Obsolete replaced with CA360 Brass ASTM B16
1730-00-225-1360 Retainer, Cup, Pump
1730-00-386-9513 SLEEVE JACK
Material Deviation: Comp 22 Obsolete replaced with CA360 Brass ASTM B16
1730-00-670-9850 Adapter
Note: No Carborize Spec??
1730-01-289-3674 Plunger, Extension Screw
1730-01-514-8755 End Plate

2510

2510-00-056-4799 PIN
2510-00-177-8309 LUG, LOCK, MORTAR BASE PLATE
Note: Obsolete Repaced with A 36.
2510-00-741-0199 BOLT, SHACKLE
2510-00-741-2376 PIN, SPRING SHACKLE
2510-00-781-8046 SUPPORT AND DISK
2510-00-781-8047 BRACKET, HOLD DOWN, DRIVER'S HATCH
2510-01-168-9886 BAR, Lifting
2510-01-180-5558 Support, Interlock
2510-01-191-8743 BAR ASSEMBLY
2510-01-198-7413 HINGE, W/SHLD, FRONT UPPER
2510-01-433-0570 Block

2520

2520-00-040-2244 RETAINER, LEVER
Deviation: Material Spec 1020-1025
QQ-S-634 replaced with C1018/1020 per ASTM A108.
2520-00-104-4603 RETAINER, POPPET
2520-00-253-1208 INSERT, TRUNNION MOUNT, TRANSMISSION

PROTOMATIC

2540

2540-00-179-7145	PLATE, CLAMPING, FAN VANEAXIAL
2540-00-234-3503	LATCH, DRIVER'S SEAT
2540-00-773-9385	PLATE
2540-00-861-7078	Case Plunger
2540-01-023-0319	PLATE, Brake Jumper
2540-01-217-8123	Support, Latch Handle Driver's Hatch
2540-01-252-8460	PLATE, REAR STRIKER, MOUNTING
2540-01-437-4768	Block, Joint, Universal

2590

2590-00-113-0789	STIFFENER, HEAT SHIELD, LOWER, REAR
2590-00-194-4686	Spacer, Metal
2590-00-226-2129	Retainer, Wire Rope 1018 ASTM a108
2590-01-102-3466	Bracket
2590-01-213-1628	Reinforcement, 'B' Beam, S 250, Shelter
2590-01-224-9241	JACK, ROAD WHEEL
2590-01-495-0534-1	Insert, Air Horn Material upgrade: ASTM A513 Ty 5 (DOM)

2815

2815-00-146-3440	Check Valve Body Collar
2815-00-146-3478	Collar and Stud Assy
2815-00-397-3314	HOUSING ASSEMBLY, VALVE, OIL PRESSURE REGULATOR
2815-00-678-3203	GUIDE, VALVE, ENGINE

2840

2840-00-876-6682	DOWEL, HOLLOW
------------------	---------------

2930

2930-00-150-7322	HUB, WATER PUMP PULLEY
------------------	------------------------

2990

2990-00-933-6569	BAR, LOWER, ENGINE MOUNT Material Deviation 1045
------------------	--

3010

3010-00-442-5911	COUPLING
3010-01-062-7588	Coupling, Drive Shaft Note: Material Deviation 520 DOM SRA TBG per ASTM513/5 (Very Similar this is MT1026)
3010-01-067-2319	Adapter

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

3020

3020-00-073-2063 PULLEY

3040

3040-00-102-9930 Bar, Slide, Driver's Seat
3040-00-152-8830 Collar, Shaft
3040-00-453-9381 LINK
3040-00-454-5086 Shaft, Steer Relay
3040-00-477-6186 Link, Switch, Lever
3040-00-497-6680 Bellcrank
3040-00-600-8949 LATCH, BACK PLATE
3040-00-734-0750 Shaft, Reverse Idler Gear
3040-00-734-6803 Pin, Straight, Threaded
3040-00-770-8373 Shaft, Shouldered (Dog Spindle)
3040-00-933-4197 RING, AXLE
3040-01-036-6582 LINK
3040-01-037-0636 Arm, Control
3040-01-073-9705 WHEEL, PERISCOPE DRIVE
3040-01-088-9401 Shaft, Shift Lever
3040-01-090-9342 SHAFT, THROTTLE LINK
3040-01-095-8789 BASE, SIGHT RING
3040-01-095-9691 Connecting Link
3040-01-106-6619 Shaft, Shouldered Steering
3040-01-106-7812-2 SUPPORT, PERISCOPE 2 (Opposite)
3040-01-109-4575 Shaft, Schedule Cams
3040-01-120-0713 SHAFT, INTERLOCK FITTING
3040-01-149-8291 ARM, FOLLOWER
3040-01-192-6781 Shaft, Level Support
3040-01-249-1518 CONNECTION LINK, RIGID
3040-01-249-3382 Shaft, Shoulder Brake
3040-01-254-5369 BRACKET, HINGE
3040-01-267-6153 Retainer, Clip
3040-01-271-0271 PIVOT ASS'Y
3040-01-281-1426 PLATE
3040-01-286-7750 PISTON, BRAKE SECOND RANGE
3040-01-297-7258 SHAFT
3040-01-330-5063 BLOCK, DBJIC
3040-01-360-9229 Shaft, Inner Door Latch
3040-01-453-9654 Link, Steering Lock Dwg/N 12460597

3110

3110-00-491-5480 RETAINER, BEARING, GEAR
3110-00-919-5411 RETAINER, BEARING
3110-01-111-5583 RETAINER, BEARING
3110-01-217-9332 Plate, Bearing
3110-01-260-0185 ROLLER
3110-01-260-0205 ROLLER

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

3120

3120-00-008-5841	Bushing Incomplete NQ
3120-00-011-0105	BUSHING, SLEEVE
3120-00-152-6279	BUSHING, SLEEVE
3120-00-153-8734	ROLLER, DOOR
3120-00-159-7047	BEARING, THRUST, PLANET PINION
3120-00-159-7049	Bushing, Metal
3120-00-180-7713	SLEEVE, BEARING
3120-00-455-6044	SLEEVE, BEARING
3120-00-471-0543	SLEEVE, BEARING
3120-00-608-5300	ROLLER, CARTRIDGE FEED
3120-00-611-6565	Bearing, Sleeve
3120-00-625-8472	ADAPTER, BEARING
3120-00-662-3370	Collar, Spacing
3120-00-679-4549	Bearing Sleeve Note: Material Clarification; Quote based on AMS4640 (C630) Alum Bronze
3120-00-679-9757	Washer, Thrust
3120-00-690-1236	Bushing
3120-00-740-9042	ROLLER
3120-00-752-1020	SLEEVE, GEAR
3120-00-766-3327	Bushing
3120-00-857-9659	SLEEVE, MAIN SHAFT
3120-00-882-4812	Cap, Torque Arm Shaft Fwd. Landing Gear
3120-01-009-9856	FIRING PIN INSULATOR
3120-01-047-0496	BEARING, TRAVERSING TUBE
3120-01-047-0497	BEARING, TRAVERSING TUBE
3120-01-048-9268	COVER
3120-01-058-2277	BEARING, LOWER NLG SHOCK STRUT
3120-01-059-6747	BUSHING, SLEEVE LANDING GEAR (17-4)
3120-01-059-6748	BUSHING, SLEEVE LANDING GEAR (630)
3120-01-076-4350	Bushing, High Pressure Bleed Air Valve (Vespel) (Mat Lead 120 Days, ETA 180 Days)
3120-01-081-4192	BUSHING
3120-01-095-1286	BUSHING, ARBOR
3120-01-098-5136-2	Bushing
3120-01-107-3184	RETAINER, BELL CRANK
3120-01-108-7902	Coupling, Rotating
3120-01-125-4397	BUSHING Handle Flanged (17 4)
3120-01-147-5858	BUSHING, TOW PINTLE
3120-01-170-9948	Roller Assembly incomplete.
3120-01-177-5792	SLEEVE BUSHING, T55 L712 ENGINE FIELD TOOLING
3120-01-184-9710	ROLLER ASSY CONTROL VALVES
3120-01-206-0054	ROLLER
3120-01-230-0032	BUSHING Incomplete NQ
3120-01-237-5009	Bushing
3120-01-251-5048	BUSHING, SLEEVE LANDING GEAR (Nylon)
3120-01-256-2309	BUSHING, SLEEVE LANDING GEAR (630)
3120-01-256-2319	BUSHING, SLEEVE LANDING GEAR (630)
3120-01-256-2322	BUSHING, SLEEVE LANDING GEAR (17 4)

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

3120-01-257-2736	BUSHING, SLEEVE LANDING GEAR (630)
3120-01-257-2737	BUSHING, SLEEVE LANDING GEAR (BeCu)
3120-01-257-2738	BUSHING, SLEEVE LANDING GEAR (17 4)
3120-01-259-9150	BUSHING, SLEEVE LANDING GEAR (630)
3120-01-264-0250	Bearing, Upper Shock Strut, Mlg
3120-01-264-6005	BUSHING, PIN
3120-01-287-2159	Collar, Thrust (Vespel,12364209)
3120-01-291-0783	Washer, Thrust (Vespel)
3120-01-298-4471	BEARING, CYLINDER
3120-01-320-7247	BUSHING PLAIN, RUDDER HINGE FITTING
3120-01-326-4360	BUSHING, PIN
3120-01-348-6037	Bushing Plain, Rudder Hinge Fitting
3120-01-374-4547	RING, STARTER PAD PILOT REPAIR
3120-01-475-1660	Roller, Park Brake
3120-01-515-5513-3	BUSHING MLG TRUNNION FITTING REWORK A 10A

3130

3130-01-107-3184	RETAINER, BELL CRANK
3130-01-162-2330	BEARING, PILLOW BLOCK
3130-01-373-2772	BEARING, PILLOW BLOCK
3130-01-457-8047	BEARING BLOCK

4310

4310-01-282-5801	Plate, Stop Umbilical Disconnect
------------------	----------------------------------

4320

4320-00-035-6671	Piston, Pump Hydraulic Hand Jack Dwg/N 52B22890
4320-00-431-9063	RING, WEARING, IMPELLER

4370

4370-00-854-6931	Fitting
4730-00-045-3940	NUT, FIRE EXTINGUISHER PULL CABLE PACKING GLAND
4730-00-335-4728	BOLT, TERMINAL
4730-00-350-4437	ADAPTER
4730-00-421-3924	COUPLING (Basic or 1)
4730-00-449-6812	ADAPTER
4730-00-679-5682	BOLT, FLUID PRESSURE LINE Deviation Material Use 1045
4730-00-690-1218	ADAPTER, Fitting and Tube
4730-00-800-2830	Adaptor, Straight Pipe to Tube 1018 ASTM A108 Incomplete
4730-00-800-4648	ADAPTER, BREATHER
4730-00-947-7464	Sleeve
4730-01-104-3805	BOLT, FRONT END TRUNNION
4730-01-112-2820	Manifold, Smoke Valve Dwg/N 2600795 Deviation: Material 5086 H116 not H111.
4730-01-173-1223	Pin
4730-01-176-0539	PLUG
4730-01-177-4153	Insert Lubricator Main Landing Gear Deviation: ASTM D4181 in Lieu of LP 392.
4730-01-186-5858	PLUG, 1 1/4" Pipe Core Hole Incomplete.

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

4730-01-198-0571 Adapter, Pipe to Hose
4730-01-291-8470 ADAPTER, STRAIGHT, PIPE TO HOSE
4730-01-294-3284 INVERTED NUT, TUBE COUPLING
4730-01-317-8298 Restrictor, Fluid Flow
4730-01-346-9291 Adapter, Pipe to Tube Male Pipe End, Flared
4730-01-387-7158 STUD, FITTING, FUEL TANK
4730-01-429-8354 Shaft, Pivot

4810

4810-01-111-2290 SPOOL, VALVE

4910

4910-01-095-6902 Cover, Hyd Pump Opening

5120

5120-00-134-7480 Replacer, Valve Seat (Exhaust)
5120-00-708-3252 Replacer, Bearing Cup Pinion and Handle
5120-00-793-5057 Wrench, Injector Turning Assembly
5120-00-966-5963 Drive Tool Lockring, Rosan Insert (1)
5120-01-060-1452 WRENCH, PLAT DRIVE, LEADING EDGEMat not available. Incomplete.
5120-01-172-2863 Tool, Installation Adjusting Traverse
5120-01-310-2236 Starter, Seal Shaft
5120-01-323-5183 WRENCH, CONNECTOR
5120-01-399-5862 Positioner, Spherical Bearing

5220

5220-00-498-8043 Gage, Go No Go, Field Maintenance Test Equipment & Tools
5220-01-041-9920 GAGE, TRACK AND SPROCKET

5240

5240-01-163-3339 NUT RETAINER

5307

5307-01-195-5184-1 Receptacle, Connector Cover
5307-01-197-8202 Spacer

5310

5310-00-136-0224 WASHER SPECIAL STRUT ASSY, NLG
5310-00-173-8983-101A WASHER, Electrical Wiring MLG, Kit
5310-00-529-9748 WASHER, Engine Side Hsg.
5310-00-596-8343 WASHER, .312ID x .600OD x .150 Thick Spherical
5310-00-737-5257 Collar, Sprag Retaining
5310-00-763-4466 WASHER, Key Rod End
5310-00-816-6407 Retainer, Track Connector
5310-00-978-2219 WASHER
5310-01-021-1522 Pad, Pressure
5310-01-031-8410 WASHER, Cylinder

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

5310-01-051-8095	Bearing, Shock Absorber
5310-01-073-7892	WASHER, Flat Hardened
5310-01-166-8580	Ring Spacer
5310-01-176-8736	WASHER Note: Vespel SPI-1
5310-01-252-7285-2	SPACER, BODY MOUNT
5310-01-271-6900	WASHER, Seal
5310-01-282-5691	Spacer, Output Gear
5310-01-371-3113	WASHER, CONCAVE
5310-01-495-9438	Nut Plate

5315

5315-00-086-3393	KEY
5315-00-276-5385	KEY, MACHINE
5315-00-304-2995	PIN CREW DOOR HINGE
5315-00-422-2830	PIN, Dowel Duct Support
5315-00-611-0376	PIN, STRAIGHT, HEADED
5315-00-617-7112	PIN, HOWITZER TRAVEL LOCK CLEVIS Deviation: Cyanide HT Replaced with .010 .015 CarboNitride.
5315-00-678-7074	PIN, GROOVED, HEADLESS
5315-00-740-9045	Pin, Hinge
5315-00-741-2106	Pin, Anchor
5315-00-753-0362	KEY, STATOR VANE
5315-00-777-3124	Pin, Straight Headless
5315-00-810-7696	Pin, Grooved Headed
5315-00-826-5358	KEY, Machine
5315-00-862-4004	Pin
5315-00-863-1046	Pivot
5315-00-909-3026	PIN, KNOB, LOCK
5315-00-923-7419	Traverser Carriage Stop, Rotary Retraction Engine
5315-01-004-3067	Pin
5315-01-011-2813	PIN Deviation: Material Upgrade 4140.
5315-01-031-6207	PIN, YOKE
5315-01-064-0563	Guide, Cover
5315-01-070-8390	Pin
5315-01-076-9553	PIN HEAD, UNIVERSAL AIRCRAFT TOWBAR
5315-01-077-1516	GUIDE, SPRING
5315-01-079-2919	PIN, Foot Rest
5315-01-081-6473	PIN, AXLE AIRCRAFT LIFTING
5315-01-093-5341	PIN (1)
5315-01-098-6467-H01	GUIDE PIN
5315-01-105-8974	Pin, Shoulder, Headless
5315-01-118-2598	PLUNGER, DETENT
5315-01-138-4805	PIN, RECOIL
5315-01-150-1525	SUPPORT, ENGINE
5315-01-185-9557	KEY
5315-01-195-0110	PIN
5315-01-217-2269	KEY
5315-01-271-3047	PIN, STRAIGHT, HEADLESS

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

5315-01-285-7796	PIN TOW BAR
5315-01-350-4195	Pin
5315-01-454-2266	PIN, GROOVED, HEADED
5315-01-475-9921	PIN, LOWER
5315-01-476-0116	PIN, UPPER
5315-01-482-3587	Stud
5315-01-496-9971	Pin, Headed

5320

5320-01-098-6766	Pin
------------------	-----

5325

5325-01-004-8109-1	GROMMET, NYLON
5325-01-073-7745	CUP
5325-01-109-4484	RING, RETAINER (this is wrong/ Do not use.)

5330

5330-01-073-7972	PLUG, ACCESSORY GEARBOX
5330-01-106-7820	Retainer, U-Joint

5340

5340-00-008-6270	Rod, Straight, Headless, BAK-14
5340-00-008-7997-1	SPRING BLOCK SUPPORT ARM ASSY. BAK-14
5340-00-072-5443	RETAINER, PERISCOPE QUICK RELEASE FRONT
5340-00-103-5779	Eye, Spring, Drivers Hatch
5340-00-303-3547	PIN-SCISSOR- Incomplete.
5340-00-454-5316	PLUG, SHAFT, SPLINED, FINAL DRIVE
5340-00-501-3611	Plunger, Cartidge Aligning Pawl
5340-00-568-8692	HINGE, Left
5340-00-615-2236	HINGE, Male
5340-00-646-8374	HOUSING, SPRING GUIDE, OUTER
5340-00-691-5553	CLAMP, RIM CLENCHING Note: Alloy 245 Temper 4, SS with Alloy 2024-T4.
5340-00-712-1362	PLUG, DUST AND MOISTURE-SEAL Deviation: 360 Brass ASTM B16
5340-00-714-4139	STOP, CAM
5340-00-745-7647	ARM, ADJUSTING, EXHAUST DEFLECTOR
5340-00-764-8300	PLATE, REST, STEERING KNUCKLE
5340-00-815-9677	PLATE
5340-00-891-1121	TRIP, RAMP LOCK
5340-00-935-5913	CONNNECTOR, CABLE
5340-00-986-8674	COVER, DRAIN, HULL FLOOR
5340-01-043-7478	CAP
5340-01-044-0267	BEARING, SHOCK ABSORBER
5340-01-045-4097	CLEVIS-ENGINE SHIPPING SUPPORT
5340-01-045-5535	CAP
5340-01-053-4866	Valve Assembly, Fuel Air Vent
5340-01-054-9733	Strike, Catch Sliding Latch-Driver Hatch
5340-01-061-7327	COVER, SUPPORT, ARM
5340-01-065-7518	COVER

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

5340-01-067-0691	CLEVIS
5340-01-073-9699	Plate, Backup
5340-01-079-3081	Plunger
5340-01-084-4938	Ferrule, 200AS123-1AB
5340-01-090-0985	LEVER Deviation: 4130-4142
5340-01-100-0520	HINGE
5340-01-103-6785	Clamp, Block Engine -2005
5340-01-107-1833	CLEVIS, SPRING RETAINER, DRIVER'S HATCH No Quote.
5340-01-113-1184	Turnbuckle Body
5340-01-114-7655	Hinge, Upper Leaf
5340-01-114-7656	Leaf, Butt Hinge
5340-01-115-0615	HINGE, LOWER LEAF
5340-01-115-3516	CLEVIS, CABLE
5340-01-129-0463	Crank, AGB Gear Train
5340-01-142-0528	GUIDE
5340-01-152-4724	Segment, Hinge, Hatch Cover
5340-01-163-3339	Nut Retainer
5340-01-171-2282	PLATE
5340-01-178-2176	CLAMP, HOSE
5340-01-179-4110	CLAMP ASSY
5340-01-180-3518	NUT, ADJUSTING
5340-01-180-5560	CLAMP, TUBE
5340-01-180-5561	CLAMP, TUBE
5340-01-180-6780	CLAMP
5340-01-181-6135	BRACKET, TUBE
5340-01-181-6450	ANGLE
5340-01-184-4865	Plug
5340-01-189-6464	BRACKET
5340-01-193-6785	Plate, Cover
5340-01-193-7095	Plate, Cover
5340-01-196-7735	Hinge
5340-01-200-6049	ARM, LOCKING
5340-01-201-0964	Clamp, Upper
5340-01-203-8608-1	HINGE, W/SHLD, FRONT UPPER (Shown)
5340-01-203-8608-2	HINGE, W/SHLD, FRONT UPPER (Opp)
5340-01-205-5957	RETAINER, CROSS HEAD
5340-01-229-3755	Turn Buckle Body
5340-01-235-0438	PLUG, DIFFUSER
5340-01-248-9633	Block, Mounting
5340-01-250-1328	CAP
5340-01-252-9809	Hinge Half Cargo Hatch
5340-01-255-0968	Retainer, Wire Rope Opening Cover
5340-01-256-6906	Nut
5340-01-259-0254	Block, Mounting Valve
5340-01-272-7758	HOLDER, SPRING
5340-01-274-8994	BLOCK, TURRET DOOR GUIDE
5340-01-286-9564	CLAMP, RIM CLENCHING(Deviation- Make with 17-4 Plate AMS-5604)

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

5340-01-286-9564-CASTING	CLAMP, RIM CLENCHING (Casting) (Incomplete)
5340-01-286-9565	CLAMP, RIM CLENCHING
5340-01-305-7719	Hinge, Cover, Combat Lock
5340-01-308-6343	PLATE, MOUNTING, INDICATOR
5340-01-310-5869	BLOCK, STOP, INNER
5340-01-310-9542	PLUG
5340-01-331-1523	TOOL, LOCK PLATE
5340-01-334-0609	COVER
5340-01-339-1153	CLAMP
5340-01-340-7078	CLAMP
5340-01-350-4281	PROTECTIVE SLEEVE Note: This material is very hard to get (HDPE Black).
5340-01-353-6819	Handle
5340-01-366-5795	AXLE POINTER
5340-01-368-2855	CLEVIS
5340-01-371-0925	Bracket, Ramp Cylinder
5340-01-376-0654	COVER, Latch
5340-01-379-0685	STANDOFF
5340-01-390-3862	CLEVIS
5340-01-395-7944	HANDLE ASSEMBLY No Quote
5340-01-409-2641	BASE
5340-01-415-1928	Cover, Brake
5340-01-421-2002	Post
5340-01-425-8648	FOLLOWER-CAM Wire Support AKA 510845-3 (Bracket, Mounting)
5340-01-443-6475	Lug, Hinge
5340-01-443-9827	CLEVIS, Slotted
5340-01-456-6963	PLATE, LATCH MOUNTING
5340-01-475-0495	HANDLE, VIEWER

5342

5342-00-312-8022	Adapter, Torque for Gunners Quadrant Know B8267842 Tel, Mt. T208
5342-00-318-7545	EYE, ENGINE LIFTING Note: C1010/1020 S/S with SAE1018 ASTM A108 (AMS 5069)
5342-00-774-6201	Index, Chassis
5342-00-793-0308	Plug, Turnbuckle
5342-01-027-1209	Nut, Special Dwg/N 8004519 (Clamp)
5342-01-098-5087	CLAMP
5342-01-126-4034	BOSS-HARNES RETAINING
5342-01-295-6972	FERRULE
5342-01-310-1807	KEEPER, WASHER
5342-01-323-8789	FLANGE
5342-01-370-7244	Arm Crank

5355

5355-00-768-7287	Adapter
5355-01-475-2831	HOUSING, KNOB

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

5365

5365-00-177-3931	RING, EXTERNALLY THREADED
5365-00-178-1312	Spacer, Gear Traversing Mechanism
5365-00-224-1835	SPACER, BEARING, MARINE CLUTCH
5365-00-413-4371	SPACER, SHEAVE
5365-00-439-2488	Bushing, Machine Thread
5365-00-446-6378	Radius Ring, Trunnion Main Rotor
5365-00-453-5374	SPACER, FUEL FILLER
5365-00-580-3815	Spacer (.79 ID x .94 OD x .65 Long)
5365-00-616-7209	LINER
5365-00-664-0094	Ring, Locking Deviation: Made from 2024-T351 Bar, QQ-A-225/6 AMS4120,ASTMB211. Mask OD Threads, Saw Slot both sides.
5365-00-740-9784	Collar, Spacer
5365-00-814-0666-7	Thrust Washer
5365-01-102-7167	SPACER, STEPPED
5365-01-113-2540	SLEEVE, HANDLE
5365-01-117-6655-3	Spacer, Control Box Mounting
5365-01-124-2636	SPACER
5365-01-125-0579	SPACER
5365-01-129-5751-1	Spacer, Torque Tube
5365-01-140-4578	RETAINER, CABLE REEL
5365-01-140-6527	Roller
5365-01-140-6758-3	Snubber, Guide Shaft Engine Transmission
5365-01-143-9791	SPACER - OIL PRESSURE TRANSMITTER P01
5365-01-148-1288	RING, EXTERNALLY THREADED
5365-01-168-0546	PAD, SHIM
5365-01-204-2104	SPACER, FIRE EXTINGUISHER MOUNT
5365-01-213-7562	SPACER
5365-01-260-0195	SPACER, AZIMUTH ADJ
5365-01-270-7574	Spacer, Plate Tow Missile
5365-01-271-0314	Spacer, Plate
5365-01-272-2622	GUIDE
5365-01-272-2808	BUSHING, SEAL
5365-01-287-5868	RETAINER, SLEEVE
5365-01-341-4188	Spacer, Sheave Assy. Moveable R.A.S.T. System
5365-01-350-6847-1	Spacer
5365-01-355-5374	Spacer
5365-01-372-3033	Mount Bushing for Reel Dwg/N 8-52N-430
5365-01-431-4603	Spacer
5365-01-432-1407	SPACER ALTERNATOR, UPPER BRACKET

5420

5420-00-050-8747 WRENCH, CYLINDER POD FLATS Deviation 4140.

5930

5930-00-045-6979-2 PLUNGER, SWITCH

Contact one of our sales staff for more information or to request a quote

PROTOMATIC

5935

5935-00-252-7679 Adapter, Connector

5940

5940-01-003-8579 STUD, TERMINAL, RECONNECTION BOARD

5970

5970-01-110-4282 INSULATOR, BUSHING

5970-01-172-7740 INSULATOR

5970-01-249-5848 Washer, Flat, Non-Metallic Special (4M116-04006)

5975

5975-01-079-2962 Nut, Coupling

5985

5985-00-792-9613-2 Shaft, Square

6150

6150-01-144-8681 NUT, ADAPTOR

8725

8725004 GUIDE, VALVE, ENGINE

Note: Made from ASTM A436 Ni Resist Iron Per obsolete Mil-G-858

Advise Specific Part Number: Std, +0.005, +0.010, +0.020.